

GLEAMCLENE



DESCRIPTION

GLEAMCLENE is designed to clean iron and steel without attacking the metal. Additionally, GLEAMCLENE cleans rust and calcium stains off toilet bowls and glass.

DIRECTIONS

IRON AND CALCIUM STAINS: Remove with GLEAMCLENE diluted between 2 to 5 times. Work up a dry wall.

METAL: Only soak steel objects in GLEAMCLENE as supplied or diluted with water up to 3 times. Do not soak aluminium, copper, or other amphoteric metals. The amount of dilution depends on the degree of rust to be removed and its age.

GLASS: Apply dilutions between 5 to 9 times with water soaked on a rag. Wipe over the window face to remove stains from reticulation or material build up. Wash down with water. Stubborn stains can be removed with undiluted GLEAMCLENE by spotting the stain and rubbing it with a rag.

TOILET BOWLS: Pour 100-200mL of GLEAMCLENE into the water in the bowl. Brush the GLEAMCLENE over the bowl and leave for 1-2 hours for light staining. For heavy staining, brush GLEAMCLENE around the bowl 3 or 4 times at 2 hour intervals, and leave overnight. Rinse after treatment with two flushes. Add 100-200 grams of sodium bicarbonate or sodium carbonate to bowl water and flush the toilet.

SAFETY

Wear safety glasses, rubber gloves, safety boots and protective clothing.

FIRST AID

SWALLOWED: Drink water or milk. Do not induce vomiting.

INHALED: Remove to fresh air.

SKIN: Wash off with water followed by soap and water.

EYES: Wash off with copious quantities of water for 15 minutes.

Seek medical advice in all cases.

CLEANING

Cleaning or washing down is done with water. Treated sites should be neutralised after washing with NEUTRA diluted 9 times with water and then rinsed again with water. 1 litre of NEUTRA makes 10 litres of an appropriate dilution.

STORAGE

Store GLEAMCLENE in a cool area, under cover and away from other chemicals or foodstuffs.

PACK SIZES

GLEAMCLENE is sold in packs of 5, 10, and 20 litres.

TRANSPORT

UN No. 1760 : CLASS 8 : SUBCLASS NONE :
HAZCHEM 2R : PACKAGING GROUP II + III :
IERG No. 37.

Before using GLEAMCLENE, either diluted or undiluted, always do a small trial on the stain to be removed so the least amount of acid is used.

FACTORY
16 GOONGARRIE STREET
BAYSWATER WA 6053
AUSTRALIA

POSTAL
PO BOX 385
BAYSWATER WA 6933
AUSTRALIA

TELEPHONE
TEL. (08) 9378 2022
FAX. (08) 9377 2575
MOB. 0418 956 860

IDENTIFICATION
PAGE 1 of 1
ISSUE: JULY 2011
REF: GMCL

QUINDALUP HOLDINGS PTY LTD (A.C.N. 009 026 386) AS TRUSTEE FOR CALMARC FAMILY TRUST (ABN 18 340 289 669)

This information is offered solely for the customer and/or specifier for their consideration, investigation and verification. The suggestions mentioned herein should be fully assessed prior to application. No warranty or implied liability is given for any recommendations, advice, suggestions made by Calmarc Chemicals or representatives, agents or distributors for the conditions of use and labour for the products which are beyond our control. Catalogue or specification contents may change from time to time without notice. M.S.D.S. is available.